

## SAFE WORK PRACTICE

<b>TITLE</b>	Clearing and/or Grading Of Pipeline Right Of Way
<b>GENERAL</b>	Protecting workers from injuries associated with clearing and grading operations
<b>APPLICATION</b>	In order to make the right-of-way a suitable work area, the removal of trees, brush and other vegetations is required.
<b>PROTECTIVE MECHANISMS</b>	Safe work procedure Permit system PPE Barricades and warning signs Manufacturers specifications Equipment maintenance procedures ERP (Emergency Response Plan)
<b>SELECTION AND USE</b>	As per safe work procedure Manufacturers specifications
<b>SUPERVISOR RESPONSIBILITY</b>	To facilitate and/or provide proper instruction to their workers on protection requirements and training Hazard assessment Work site inspection
<b>WORKER RESPONSIBILITY</b>	<ol style="list-style-type: none"> <li>1. Inspect equipment prior to use (walk around).</li> <li>2. Stay within an operator's vision.</li> <li>3. Be aware of power line proximity.</li> <li>4. Watch for falling objects.</li> <li>5. Use care and caution when using chain saws.</li> <li>6. Be aware of the falling zone when felling trees.</li> <li>7. Use recommended ointments and repellents.</li> <li>8. Do not ride on equipment unless appropriate seating is available.</li> <li>9. Do not stand between winch and object being moved.</li> <li>10. Do not leave equipment running while fuelling.</li> </ol>

\* The information presented in this publication is intended for general use and may not apply to every circumstance. It is not a definitive guide to government regulations and does not relieve persons using this publication from their responsibilities under applicable legislation. The Northern Safety Association does not guarantee the accuracy of, nor assume liability for, the information presented here. Individual counselling and advice are available from the Association.